

PARALLEL SYSTEMS

COMPUTER PROGRAM CASSETTE

* This program is for use with only the ADAM™ Family Computer System. Follow the directions in your Set-Up Manual for getting started and using the ADAM. Once your ADAM is assembled, proceed with the following procedures.

1. Turn on the ADAM Computer.
2. You must now load ADAM'S "SMART BASIC™".
3. Insert the "SMART BASIC" digital data pack into the digital data pack drive on the Memory Console; close the drive door.
4. Press forward the COMPUTER RESET switch on the top of the Memory Console.
5. The "SMART BASIC" will now start loading into your ADAM Computer.
6. Wait approximately 1 minute until the data pack stops moving and a bracket () with a flashing cursor (-) appears on the screen. You are now ready to load the Parallel Systems Program.
7. Remove "SMART BASIC" and replace it in its protective case. Now insert the Parallel Systems digital data pack program into the drive.
8. Before proceeding, make sure "LOCK" key on ADAM'S keyboard is set for lower case operation.
9. Type run ps (lower case) then press RETURN KEY.
10. After approximately 1-2 minutes your Parallel Systems Program will start automatically. Remove data pack and return it to its protective case.
11. If you experience difficulty in loading the program, refer to the Routine and Troubleshooting Sections of your ADAM Set-Up Manual.

ADDITIONAL DATA

- * If you have any problems, please call our 24 hour number for applications assistance (609) 227-9634.
- * After any program is loaded into the computer, remove digital data pack from drive and return it to its protective case.
- * When using a program which stores information on a digital data pack, do not use the program digital data pack to store data. Use a separate digital data pack.
- * When entering data into the computer never use a comma (,).

— SPECIAL INSTRUCTIONS FOR HOME BUDGET PLANNING —

* This program is designed to utilize continuous roll or fanfold paper for printouts. If single sheets of 8½ x 11 paper are used, touch the CONTROL key and the S key simultaneously to stop the printer at the end of each sheet. After inserting a new blank sheet, touch the CONTROL key and the Q key simultaneously to continue printing on the new sheet.

Parallel Systems ADAM LIBRARY

- * Home Budget Planning #26001-A
- * Home Files Manager #26002-A
- * Personal Checkbook Manager #26003-A
- * States & Capitals #26004-A
- * World Capitals #26005-A
- * Great Inventions #26006-A
- * Party Trivia #26007-A

ADAM and SMART BASIC are registered Trademarks of Coleco Industries, Inc.